

May 13, 2014

Michael Jacobs Sureshield Coatings Company 350 Northgate Parkway Wheeling, IL 60090 USA

Antifungal Assessment of One Filter Media Sample

3006131

One filter media sample, treated with Ultra-Fresh DW-56, was received from Sureshield Coatings Company on April 09, 2014. At Thomson Research Associates Inc., the sample was tested for resistance to mixed fungal growth using a standard test procedure.

PROCEDURE

Fungal Resistance Test:

ASTM Method G-21-13 "Determining resistance of synthetic polymeric materials to fungi" was used to test the specimen. In brief, the specimen was placed onto a mineral salts agar medium and then inoculated with a mixed fungal spore inoculum consisting of equal numbers of spores of the following species:

Aspergillus niger (ATCC #6275) Chaetomium globosum (ATCC #6205) Penicillium funiculosum (ATCC #11797) Aureobasidium pullulans (ATCC #15233) Trichoderma virens (ATCC #9645)

The inoculated specimen is then incubated at 28C for 28 days, in order to allow adequate time for mature fungal growth to appear.

THOMSON RESEARCH ASSOCIATES INC.

49 Gervais Drive, Toronto, Ontario, Canada, M3C 1Y9 Tel: 416.955.1881 • Fax: 416.955.1887 • Email: <u>lab@ultra-fresh.com</u> Ultra-Fresh is a registered trademark of Thomson Research Associates Inc.

RESULTS

Sample Description		ASTM G-21-13			
		7 days	14 days	21 days	28 days
1	Fellowes filter media (flat filter) treated with Ultra-Fresh DW-56 from ZFT (China facility)	0	0	0	0

Notes:

G 21-13

0 = specimen remained free of fungal growth.

1 = traces of growth on specimen (less than 10%).

2 =light fungal growth on specimen (10 to 30%).

3 = medium fungal growth on specimen (30 to 60%).

4 = heavy fungal growth on specimen (60% to complete coverage)

CONCLUSION

In the ASTM G-21-13 Test, the sample remained free from mixed fungal growth after 28 days of incubation.

THOMSON RESEARCH ASSOCIATES INC.

Microbiology Manager

c: Dave Klein

Microbiologist

THOMSON RESEARCH ASSOCIATES INC.

49 Gervais Drive, Toronto, Ontario, Canada, M3C 1Y9 Tel: 416.955.1881 • Fax: 416.955.1887 • Email: <u>lab@ultra-fresh.com</u> Ultra-Fresh is a registered trademark of Thomson Research Associates Inc.